

# FLYING SCOT®

## Grab Rail Installation Instructions

### Kit Includes:

- 1 Grab Rail with Integral Bolts
- Fender washers & lock nuts

### Additional Materials Required:

- Pencil
- Drill with 5/16" bit
- Gel coat, Resin, or any good Marine Sealant

**Before Beginning Please Read Through All Instructions.**

**Please call us at 1-800-864-7208 with any questions.**

### Installation:

1. Draw a line parallel to the centerline of the boat measuring from the gunwale edge. The line should be approximately 6" in from the gunwale aft and 6 ½" forward.
2. Draw another line 3" from the transom edge.
3. Place one end of the grab rail at the intersection of the lines and mark where the two bolts would be on the deck
4. Use a 5/16" drill bit and drill the two holes

***Note:*** You will be drilling through balsa so it is **VERY IMPORTANT** to seal the edges of the holes well. We use gel coat, but you could also use resin or any good marine sealant

5. Caulk holes well from the outside
6. Install grab rail
7. Use the large fender washers under the deck and secure with the lock nuts

***Note:*** **DO NOT** over tighten the nuts! If the nuts are too tight, the core may compress and cause a dimple in the deck surface

